

RV APPLIANCE POWER CONSUMPTION

WHAT CAN YOU RUN ON 30 OR 50 AMP HOOKUPS?

TYPICAL RV POWER CONSUMPTION ITEMS

(The Watts and Amps below are typical. Some appliances may require more or less depending on their efficiency and size.)
Knowing what's running can prevent a breaker from tripping!

APPLIANCE	RUNNING WATTS	AMPS @115V
Air Conditioner*		
Rooftop 13,500 BTU	1600	14
Rooftop 15,000 BTU	1700	14.5
Dual Basement 27,000 BTU	2000	18.5
Blender*	300	2.6
Blow Dryer*	900-1500	7.8-13
Can Opener	120-300	1.0-2.6
CD/DVD player	35-100	0.3-0.9
Clock Radio	50	0.4
Coffee Maker (4-10 Cup)	600-1200	5.7-10.4
Computer		
Desk Top & Monitor	100-400	0.9-3.5
Laptop	50-75	0.4-0.7
Printer	60-240	0.5-2.1
Crockpot	250	2.2
Curling Iron / Straightener	300-800	2.6-7.0
Electric Blanket	500	4.3
Electric Fry Pan	1200	10.4
Electric Water Heater (6gal)	1440	12.5
Fan	40-300	0.4-2.6
Furnace Fan* (1/3 HP)	1200	10.4
Heating Pad	250	2.2

APPLIANCE	RUNNING WATTS	AMPS @115V
Hot Plate	1200	10.4
Iron	1000-1500	8.7-13.0
Microwave (600-1000 Cooking Power)	1100-2000	9.6-17.4
Mini Lights (Christmas Type)	25	0.2
Popcorn Popper	275-600	2.4-5.2
Power Converter	575-800	5.0-7.0
Refrigerator / Freezer*	400-1200	3.5-10.4
Satellite Dish & Receiver	200-250	1.7-2.2
Shaver (Electric)	35	0.3
Space Heater	1000-1500	8.7-13.0
Stereo	30-100	0.3-0.9
Toaster	800-1500	7.0-13.0
Toaster Oven	1200	10.4
TV		
19" Color	160	1.4
25" Color	300	2.6
13" Color VCR Combo	230	2
Vacuum*	200-1100	1.7-9.6
VCR	40-60	0.3-0.5
Waffle Iron	1200	10.4
Washer / Dryer*	600-1900	5.2-16.5

*Appliances with large motors/compressors may require 3 to 7 times the listed wattage/current when starting



FOR MORE GREAT INFORMATION, PLEASE VISIT US AT
OptingOutOfNormal.com